

**KitchenAid®**


**36" ELECTRIC BUILT-IN COOKTOP**

**MODELS:**

KCES556HBL00 (Black)

KCES556HSS00 (Stainless)

# COOKTOP PARTS



# COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	10	W10437094	Switch, Infinite (Left Front)	13	4455917	Bracket, Cooktop Mounting
	W11206696	Instructions, Installation		W10437097	Switch, Infinite (Left Rear)	14	3400093	Screw
	W11245478	Instructions, Undercounter Installation		W10843843	Switch, Infinite (Center Rear)	15	7101P426-60	Screw
	W11161586	Guide, Use & Care		W11117250	Switch, Infinite (Right Front)	16	7101P309-60	Screw
	W11238366	Diagram, Wiring Cooktop		W10578768	Switch, Infinite (Right Rear)	17	W11175342	Rail, Short
2	W11120992	Black		W10342780	Element (1300W) (Left Front)	18	W11175345	Rail, Horizontal
	W11120993	Stainless	11	W10187839	Element (3000W) (Left Rear)	19	W11177349	Top, Foam (Heat Shield)
3		Trim, Stainless (Not Serviced)		8273993	Element (1800W) (Center Rear)	20	W10471482	Switch, TOD High Limit
4	W10340209	Shield, Switch		W11117008	Element (3200W) (Right Front)			FOLLOWING PARTS NOT ILLUSTRATED
5	W10225448	Spring, Element		8273994	Element (1200W) (Right Rear)	W11110554		Harness, Main
6	W11215841	Plate, Switch		3183956	Seal, Switch Cover	3192439		Seal, Limiter
7		Grommet				7101P426-60		Screw (For Main Harness)
	W10593536	Stainless				8286642		Tape, Foam
8		Box, Burner (Not Serviced)				W11183281		Insulation, Cooktop
9		Knob, Control	12					
	W10884728	Stainless						

# OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		ACCESSORIES
	W10355016	Cleaner, Stainless Steel
	WA906B	Scraper, Cooktop
	W10355051	Cleaner, Cooktop
	31605	Kit, Cooktop Care