


KitchenAid®

REFRIGERATOR

MODELS:

KRQC736RPS00 (Stainless)


CABINET PARTS



CABINET PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	7	W11088974	Jumper Wire Assembly, Hinge Cover Switches	13	W11351740	Bottom Hinge and Leveler Assembly (Left Hand)
	W11689443	Owner's Manual						
	W11712181	Tech Sheet	8	W11171145	Sensor, External Humidity	14	W11351739	Bottom Hinge and Leveler Assembly (Right Hand)
2		Cabinet (Not a Serviceable Part)	9	W11306513	Pivot Block, Mullion			
3	W11314383	Cover, Hinge	10	W11654043	Screw Cover			
4	W11097769	Top Hinge (Left Hand)	11	W11334827	Center Hinge (Left Hand)			
5	W11097767	Top Hinge (Right Hand)	12	W11334651	Center Hinge (Right Hand)			
6	W11115055	Switch, Reed						








SHELF PARTS



SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11675223	Tuck Shelf Assembly	5	W11675220	Crisper Pan Assembly	7	W11293350	Door, Filter
2	W11293792	Full Shelf Assembly	6	W11675221	Pantry Pan Assembly	8	W11688907	Platter Assembly
3	W11293737	Glass, Crisper Cover						
4	W11734172	Frame Assembly, Refrigerator Drawers						


FREEZER DRAWER PARTS



FREEZER DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11688905	Pullout Tray Assembly	5	W11675499	Drawer Assembly, Bottom Right	8	W11293497	Adapter Plate Assembly, Bottom (Left Hand)
2	W11675501	Drawer Assembly, Middle Left	6	W11293511	Adapter Plate Assembly, Top (Left Hand)	9	W11293495	Adapter Plate Assembly, Bottom (Right Hand)
3	W11675503	Drawer Assembly, Middle Right	7	W11293509	Adapter Plate Assembly, Top (Right Hand)	10	W11734929	Wine Caddy
4	W11675497	Drawer Assembly, Bottom Left						


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	7	W11186092	Fan, Evaporator	12	W11298026	Thermistor, Evaporator Defrost
2	W11310004	Light Strip, LED	8	W11049305	Rear Cover, Evaporator Fan	13	W11389906	Heater, Defrost
3	W11734246	Air Tower Assembly	9	W11171146	Sensor, Internal Humidity	14	W11294152	Shelf Support (Front Left/Rear Right)
4	W11135456	Thermistor, Temperature	10	W11309023	Evaporator Cover Assembly, Refrigerator	15	W11294154	Shelf Support (Front Right/Rear Left)
5	W11654043	Screw Cover	11	W10920204	Evaporator, Refrigerator			
6	W11049306	Front Cover, Evaporator Fan						


FREEZER LINER PARTS



FREEZER LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	8	W11389905	Heater, Defrost	12	W10909729	Evaporator, Convertible Compartment
2	W11174204	LED Module	9	W11320021	Evaporator Cover Assembly, Freezer	13	W11384548	Evaporator Cover Assembly, Convertible Compartment
3	W11091630	Bracket, Ice Box Fan	10	W11135456	Thermistor, Temperature			
4	W11251035	Seal, Ice Box Fan	11	W11186092	Fan, Evaporator			
5	W11284795	Fan, Ice Box						
6	W11091622	Evaporator, Freezer						
7	W11298026	Thermistor, Evaporator Defrost						


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11734728	Door, Refrigerator Right Hand	11	W11110857	Stopper, Door	22	W11292787	Gasket, Supply Duct
2	W11734732	Door, Refrigerator Left Hand	12	W11306079	Latch, Door Closer (Right Hand)	23	W11292789	Clip, Return Duct Gasket
3	W10518672	Badge	13	W11306401	Latch, Door Closer (Left Hand)	24	W11292785	Gasket, Return Duct
4	W11654051	Mullion, Door	14	W11361143	Ice Maker Assembly	25	W11024885	Magnet, Switch
5	W11376604	Gasket, Refrigerator Door	15	W11316216	Ice Bin Assembly	26	W11672547	Handle Kit (Includes 2 Refrigerator and 2 Freezer Handles)
6	W11035875	Switch, Rocker Arm	16	W11130119	Coupling, Auger	27	W11755083	Stud, Handle Mounting
7	W11734590	Door Assembly, Ice Compartment	17	W11290983	Trivet, Ice Compartment Door			
8	W11312188	Plate, Ice Chute	18	W11290988	Bin, Medium Door			
9	W11357426	Shaft, Dispenser Motor	19	W11636291	Bin, Gallon Door			
10	W11391787	Dispenser Motor	20	W11675222	Bin, Stadium Door			
			21	W11292783	Clip, Supply Duct Gasket			


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11300274	Door, Freezer Right Hand	6	W11110857	Stopper, Door	11	W11290989	Bin, Tall Freezer Door
2	W11300254	Door, Freezer Left Hand	7	W11306079	Latch, Door Closer (Right Hand)	12	W11672547	Handle Kit (Includes 2 Refrigerator and 2 Freezer Handles)
3	W11306509	Seal, Vertical	8	W11306401	Latch, Door Closer (Left Hand)	13	W11755083	Stud, Handle Mounting
4	W11306511	Seal, Horizontal	9	W11306327	Gasket, Freezer Door			
5	W11024885	Magnet, Switch	10	W11290985	Bin, Freezer Door			


DISPENSER PARTS



DISPENSER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11679238	User Interface	3	W11678170	Housing Assembly, Dispenser (Includes Switches)	4	W11414342	Grate, Drip Tray
2	W11310097	Motor and Bracket Assembly, Ice Door				5	W11414340	Drip Tray


WATER SYSTEM PARTS



WATER SYSTEM PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11628207	Tube, Water (Valve to Hinge, Ice Maker)	4	W11125031	Housing, Water Filter	8	W11293058	Cover, Water Valve
2	W11628075	Tube, Water (Valve to Hinge, Dispenser)	5	W11166019	Heater, Water Filter	9	W10680605	Filter, Water
3	W11451854	Water Box Assembly	6	W11167973	Valve Assembly, Dual Water	10	W11332415	Cap, Water Filter
			7	W11083973	Reservoir, Water	11	W11432232	Valve, Water Inlet
						12	W11135271	Guard, Water Valve

UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11700397	Control Board	9	W11037729	Fan, Condenser	17	W11039081	Cover, Machine Compartment
2	W11029002	Lid, Main PCB	10	W11165514	Condenser	18	W11368461	Cord, Power
3	W11385399	Line Filter	11	W11304825	Bracket, Condenser			REFRIGERANT CHARGE
4	W11728019	Suction Tube	12	W11093946	Drain Tube			59 grams (R600a)
5	W10805035	Drier (Service Drier Without Dye)	13	W11327053	Drain Tube			
6	W11675958	Compressor Assembly	14	W11305915	Drain Pan			
7	W11675965	Inverter	15	W11027541	Plate, Compressor Base			
8	W11245686	Valve Assembly, 4-Way Refrigerant	16	W11083695	Cover, Compressor Roller			