## Installation Instructions

# Filler Panel Kit

#### FOR 36" INSTALLATIONS



Kit	Model
JX36B	CVM519
	CVM721
	CVM1750
	CVM1790
	CSA1201
	CVM517
	CVM521
	JVM3160
	JVM3162
	JNM3163
	JVM6172
	JVM6175
	DVM7195
	JVM7195
	JNM7196
	PSA9120
	PSA9240
	PVM9005
	PVM9179
	PVM9215
	PNM9216
	QVM7167
	RVM5160

#### **TOOLS YOU WILL NEED**

• Phillips screwdriver



Install the OTR bracket according to OTR Installation Instructions.

**NOTE:** This kit is best installed with 12" base cabinets. Cabinets with greater than a 12" base may have a larger gap between back wall and kit.

**NOTE:** Ensure the OTR and the Cooking Product installation manuals are followed.

### **KIT INSTALLATION**

- 1. Place the microwave on a flat surface where you can work on the bottom of both sides.
- 2. Remove all 3 pieces from the package (right panel, left panel, top brace.
- 3. Remove the screws from the lower back corner of the microwave.
- 4. Your microwave will have 1-3 screws on the bottom left side. Remove these screws to create a gap between the bottom plate and the case of the microwave.



- 5. With the short edge of the side trim to the back of the left side of the microwave, slide the lower lip of the side panel inside the gap between the bottom plate and the case.
- Attach the side trim to the back of the microwave using the screw removed in step 3, then reattach the screws removed in step 4 to the underside of the microwave.



7. Make adjustments so the side panel is in line with the front of the microwave case.



- 8. Repeat the same procedure for the other side.
- 9. Using the 2 flat head screws provided, attach the top brace to the 2 side panels to pull both panels together.



#### Must use two forward holes for the top brace

10. Install the over-the-range microwave with side panels into the 36" opening.

**NOTE:** Make sure you have installed the mounting wall bracket in the center of the 36" opening per the installation instructions provided with your microwave.